



# DDT60K Differential Pressure Torque Chart



Pressure (PSI)	500	750	1000	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000
Hi Spd/Lo Tqe (Ft-Lbs)	3033	4550	6067	7584	9100	10617	12134	13650	15167	16684	18201	19717	21234	22751	24267	25784	27301	28818	30334
Lo Spd/Hi Tqe (Ft-Lbs)	6067	9100	12134	15167	18201	21234	24267	27301	30334	33368	36401	39435	42468	45501	48535	51568	54602	57635	60669

# DDT60K Differential Pressure Torque Chart



\*\*\* It is imperative that when cross referencing the pressure to torque figure that you are aware what mode the two speed motor is in. (High Speed or Low Speed). \*\*\*

Pressure (Bar)	34	52	69	86	103	121	138	155	172	189	207	224	241	258	276	293	310	327	345
Hi Spd/Lo Tqe (Nm)	4113	6169	8226	10282	12338	14395	16451	18508	20564	22620	24677	26733	28789	30846	32902	34959	37015	39071	41128
Lo Spd/Hi Tqe (Nm)	8226	12338	16451	20564	24677	28789	32902	37015	41128	45241	49353	53466	57579	61692	65805	69917	74030	78143	82256