


# V50K Differential Pressure Torque Chart



\*\*\* It is imperative that when cross referencing the pressure to torque figure that you are aware what mode the two speed motor is in. (High Speed or Low Speed). \*\*\*

Pressure (PSI)	1000	1200	1400	1600	1800	2000	2200	2400	2600	2800	3000	3200	3400	3600	3800	4000	4200	4400	4600	4800	5000	
Hi Spd/Lo Tqe (Ft-Lbs)	5154	6184	7215	8246	9277	10307	11338	12369	13399	14430	15461	16491	17522	18553								
Lo Spd/Hi Tqe (Ft-Lbs)	10307	12368	14430	16491	18553	20614	22675	24737	26798	28860	30921	32982	35044	37105	39167	41228	43289	45451	47412	49474	51535	